

FC23 - <offline>

"SIMULATION"

Name:
Author: Cristian
Time stamp Code:
Lengths (block/logic/data): 00174 00076 00000

Family:
Version: 0.1
Block version: 2
Interface: 02/05/1999 08:37:36 AM

Name	Data Type	Address	Comment
IN		0.0	
OUT		0.0	
IN_OUT		0.0	
TEMP		0.0	
RETURN		0.0	
RET_VAL		0.0	

Block: FC23

Network: 1

**Symbol information**

M97.1 START_SIMUL

Network: 2

```

S "START_SIMUL" M97.1
S "Emerg.Stop*" I0.0
S "Equipm.Stop*" I0.3
S "Emerg.*MCP" I2.6
S "Not emerg.From Pilz" I3.7
S "Emerg.* SCP" I6.2
S "Over Current resist." I5.6
S "Over Current Cab.fans" I5.7
R "Sel.Remote Mode MCP" I2.0
S "Sel.Local Mode MCP" I2.1
R "Sel.Pump Auto MCP" I2.2
S "Sel.Pump Manual MCP" I2.3
R "Start Button MCP" I2.4
S "Stop Button* MCP" I2.5
S "Stop Button* Pump#1 MCP" I5.0
S "Stop Button*Pump#2 MCP" I5.1
S "Stop Button*Pump#3 MCP" I5.2
S "Stop Button*Pump#4 MCP" I5.3
S "Stop Button*P. C#1 MCP" I5.4
S "Stop Button*P. C#2 MCP" I5.5
R "Sel.Remote Mode SCP" I6.0
S "Sel.Local Mode SCP" I6.1
S "Low Press (115 Bar)" I9.2
S "High Press (125 Bar)" I9.3
S "H#1 Pump Filter Obstruc." I9.4
S "H#2 Pump Filter Obstruc." I9.5
S "H#3 Pump Filter Obstruc." I9.6
S "H#4 Pump Filter Obstruc." I9.7
S "C#1 Pump Filter Obstruc." I10.0
S "C#2 Pump Filter Obstruc." I10.1
S "Oil Line Filter #A Obst." I10.2
S "Oil Line Filter #B Obst." I10.3

```

S "Aux.Dr.Filter Obstruct." I12.0

Network: 3

M001: BE